

WIRELESS FAN-LINK INTERCOM

OPERATING INSTRUCTIONS

GMRS RADIO OPERATION – MIDLAND MODEL GXT720

You should read the operating manual for the GMRS radios. Note the section on the 121 available tones. You will need to program the channel (1-36) that you plan to use and the tone (CTCSS 1-38) OR (DCS 1-83) you are going to use on the channel you select. It is not a bad idea to write the channel and tone on a piece of paper and tape it to the back of the GMRS radio just in case the radio gets changed from your set channel and tone. You don't want to be 1/2 mile away and can't get in touch with your race partner. Radios at noisy tracks will need maximum volume (setting 8).

GMRS RADIOS

To communicate with these units you must be on the same channel and tone (note you can use the GMRS radios separate from the headsets when you desire). The GMRS radios are powered by (4) "AA" batteries or the included "rechargeable pack" (molded pack). This unit includes the recharger stand and AC wall adapter. Recharges molded rechargeable pack only.

INTERCOM OPERATION

To operate the intercom you must have the GMRS radios turned "on" and connected to the headset. PRESS THE "PTT" BUTTON ON THE TOP OF THE LEFT EAR CUP OF THE HEADSET TO TALK (RELEASE IT WHEN YOU STOP TALKING). This model GXT720 is equipped with a cable that has a PTT (push to talk) button in the middle of the cable and also includes a volume control for the two-way radio. DO NOT press the talk button on the GMRS radio—you will pick up background noise in the area through the GMRS mike.

SCANNER AND GMRS RADIO CABLES

When headsets are stored, the cables should be disconnected from the headsets and placed in the plastic bag in which they were shipped (4" x 9" resealable bag).

ADDITIONAL HEADSETS CAN BE ADDED

Extra headsets with cables and GMRS radios can be added to this system at any time.

NOTE: WITH NOISE REDUCING MICROPHONES ON THESE HEADSETS YOU MUST KEEP THE MICROPHONE VIRTUALLY RIGHT AT THE TIP OF YOUR LIPS AND SPEAK UP WHEN YOU TALK.

NOTE: There is a lot of talk on FRS/GMRS radios around race tracks prior to and after the race. During the race, when you want to talk, there is very little talk due to the noise level. Most fans do not have a unit that can be used during this period. Other radios are not a factor. You have 2662 combinations of channels and tones from which to choose.

FREQUENCY FAN CLUB

1-800 RACE FAN

www.racescanners.com